FUTURA PRO NA QUICK START GUIDE

- The FUTURA PRO SOFTWARE OPERATING GUIDE is on the tablet (refer to Chapter 10 of the Operating Manual for instructions to access the guide). It is recommended that you register the machine and update the software prior to operation in order to ensure that you have the latest firmware and database available. Please refer to the Software Operating Guide Section 7 "MACHINE UPDATE AND REGISTRATION" to see the four methods available to register and update the machine. You might find it helpful to download the *Silca Remote Service Program* (method 3) to a local PC for use in registering and updating the software of your Futura PRO machine. Once you have downloaded the SRS program onto your PC you can use it any time to update the SW for your machine.
- 2. Setting up the Futura PRO machine (review section 3 "Machine Installation and Preparation" of the Futura PRO operations manual)
 - a. The machine may be shipped with a steel rod installed on the laser cut side of the machine. Please remove this rod and install the proper cutter (01LW for most Laser style keys or 01D for Dimple style keys) into the cutter spindle.
- **3.** Setting up the tablet (review section 4 "Tablet Regulation and Use" of the Futura PRO operations manual). Make sure that the tablet has a full battery charge prior to use. The top USB port on the back of the machine can be used to charge the tablet and to keep the tablet charged during use.
 - a. Find the "Settings" icon in the list of applications on the tablet. Press and hold the "Settings" icon and slide it to the home screen for ease of access in the future.
 - b. Open the "Settings" application by tapping the icon.
 - c. Ensure that "Wi-Fi" is on
 - d. Language and Input the tablet is set to English (United Kingdom) by default. Select English (United States) or any other language that you prefer.
 - e. Select Silca Keyboard (if desired)
- 4. Connecting the Futura PRO to the tablet. The Futura PRO software actually resides in the electronic board of the machine. The tablet holds the application (or APP) to run the software. Each time you update the SW on the machine, you should also update the Futura APP (see section 7.3 of the SOFTWARE OPERATING GUIDE). The Futura PRO machine can be set up in one of four modes in order to communicate with the tablet. Review section 6.3.4 of the Software Operating Guide to select the mode you prefer to use. The machine comes from the factory set in Access Point mode. If there are strong Wi-Fi signals located near where you plan to place the machine, you may want to use Tethering USB mode (for connecting the tablet to the machine via cable) to avoid issues connecting the tablet via the Wi-Fi signal.

To connect using Access Point Mode:

- a. Turn the machine on by turning the red emergency stop button counter-clockwise until it pops out and the white light comes on signifying that the machine is powered up. When the machine and tablet are switched on the connection automatically activates in around two minutes; if not, check the Wi-Fi connection from your tablet to see if the machine is included in the Wi-Fi networks that are found (the Futura PRO machine will appear as Silca-Futura_... If it does not show that it is connected, pick "Silca-Futura_..." and input the password which corresponds to the Futura PRO serial number (made up of 13 numbers).
- 5. **Program Start:** To start the Silca mobile program, tap the icon "Silca Futura" on the tablet's home screen. Once you hit the icon a screen will pop-up with the message "Please wait, reloading...". It will take a few minutes for the software to

download once the tablet has made connection with the machine. If the program does not start, check the settings/use (see Ch. 6.3.4).

6. Setting up the Silca Software .

Once the Silca program has opened, select the **"Options"** box to set-up the software for ease of use (review section 5 "Options" of the Software Operating Guide.

- a. Select "Settings" > "Options" > "General"
- b. "Measurement Unit" change to Thousandths of Inch.
- c. "Language " the software comes set to "English" by default. Here you can select any other language in which you want to display the information.
- d. "Reference Key Manufacturer" select "Ilco" to display the Ilco key blanks as a reference in the database.
- e. "Preferences Standard Key" it is recommended that you select the two boxes for "cutting check" and "check installed key". A check mark should appear in each box (save your settings). "Use any clamp" is enabled as a default (refer to section 6.3.3.b for explanation of each function).
- f. "Preferences Dimple/Track Key" Set preferences is used to enable or disable the use of the 01T tracer. Select the box "Use mobile Tracer" to activate the 01T tracer for decoding dimple and track keys (save your settings).
 If the field is not selected the 02T tracer is required and will need to be placed in the cutter shaft each time you need to decode a key.

Once you have selected all of your options, slide you finger from the left edge of the tablet towards the right side. A menu should appear. Select "Reload" to save all of your options to the software.

7. Calibrations – the edge cut clamp (01V), the dimple/track key clamp (01R) and the 01J and 02J jaws were calibrated at the factory so no further calibration is required to use these components. Any other optional jaws or clamps that may be included or purchased at a later date must be calibrated to the machine prior to use. Remember to replace the cutter with the 02T tracer when calibrating the laser/dimple clamps or jaws. The Mobile Tracer (01T) must also be calibrated prior to decoding dimple or track keys. *Prior to beginning any calibration procedure, make sure that the surfaces of the clamp and jaws are clean of all metal shavings* (refer to the Software Operating Guide Section 5.2 for further assistance).

Your Futura PRO machine is now ready to cut keys!

Navigating the Silca software

If you are still in the Options menu, tap the home button at the top of the screen to return to the main operating menu for the Silca program. Please review the Software Operating Guide of the Futura PRO.

Here are a few tips to get you started.

1. **Search** – this menu is used to select a category of Series Searches. In each menu there is a variety of information you can enter to narrow your search. The more information you put in, the shorter the search list will be.

- a. Standard Keys restricted for search of edge cut commercial and residential flat keys.
- b. Vehicle Keys restricted for search of edge cut and track type (laser) vehicle keys.
- c. Dimple/Track keys used to search for dimple/track keys (other than automotive)
- d. Full Key Searching not restricted to the categories above.
- e. Transponder Guide The Transponder Guide contains all of the transponder key copying solutions provided by Silca (refer to Ch.10)
- Copy by Original this menu is used to make an "exact" copy of an edge cut key (only) by means of a laser reader. If you want to cut an edge cut key back to OEM specifications, you must use the Search menu and select decoding once the "Card" is opened. All laser or dimple/ track keys must be decoded to copy.
- 3. Favorites this menu is used to access a series of searches previously set-up as favorites (refer to CH 4).

NOTE REGARDING VEHICLE SEARCH: We are constantly working with Silca to ensure that the database in the Futura machine is current and up-to-date for the North American market. Some vehicles are sold worldwide and may use a different lock systems or code series in different parts of the world so the database may not be 100% correct. If you know the code series used for the key you are trying to cut, you may find it easier to do a search by code rather than by make and model. Another good reference is the Ilco *Auto Truck Key Blank Reference* that is available from your Ilco distributor at no charge. This reference is updated every year and may be the most accurate database for vehicles in the North American market. If you notice a code series is missing or know of a new code series coming out for a particular make and model please let us know and we will attempt to get it added to the database as quick as possible.